



Palm Application Reader



PRACTICAL LOCATION DOWNLOAD

When time is critical, or your location requires portable download capabilities, Temprecord versatility can help you with our Palm Application Reader.

- Read your Temprecord data recorder on site
- Check recorder status
- View graph information
- Start, stop and reuse recorder
- Up load to PC automatically with "Hot sync"
- Serial RS232 or Bluetooth connectivity



Palm Application Reader

Reads your Temprecord Recorder on site

The Temprecord Palm reader and programme allows you to work with your Temprecord recorder on site. This allows for fast evaluation of the transported products, reducing down time during the transportation process or avoiding the necessity of removing the recorder from its environment.

Check recorder status

Check the recorder status at anytime, anywhere with the Palm application software.

View graph information

The Palm application allows you to view the entire trip in graph format. A simple touch of the Palm screen allows for easy zoom in and out features.

Start, stop and reuse recorder on site

The Palm application allows you to evaluate your trip and products transported, start, stop and reuse the recorder ready for the next application.

Up load to PC automatically with "Hotsync"

When you have finished on site simply slip the Palm into its PC cradle and your Temprecord data will be downloaded to your computer ready for normal use with Temprecord for Windows.

• Palm is a registered trademark. Palm is not supplied with application reader.
 • Windows is a registered trademark.



| Parameter | Specifications |
|------------------------|--|
| Battery type | 9 volt, replaceable Panasonic 6LR61 or equivalent |
| Interface | Serial RS232/Bluetooth |
| Case protection | IP40 Rated protection |
| Warranty period | 12 months from date of purchase |
| Palm Cradle | All model adjustable |
| Dimensions | 94x160x24mm 200grams ~ 3.7x 6.3 0.9inches and Color 7.05 Oz ~ Grey |
| Compatibility | |
| Palm Operating systems | Palm OS Software version 3.0 or higher |
| Palm Hotsynch Manager | Version 3.0 and above |
| PC Operating system | Windows 95 / 98 / 2000 / Millennium / XP |
| Temprecord Software | Version 3.18 or above |
| Functions | |
| Start Recorder | Yes |
| Stop Recorder | Yes |
| Reuse Recorder | Yes |
| Recorder Status | Yes |
| Graph & Limits lines | Yes |